



Applicable requirements :
Standard(s) for Electric Vacuum Cleaning Machines and Blower
Cleaners (UL-1017)

Characteristics



Cleanroom
Compatible



Pharma
Applications



ULPA - Included



Stainless
Steel
General



Accessories
Included



Low Noise



Dry Recovery



High Filtration
Efficiency Unit



- ULPA filter with an efficiency of 99.999% at 0.12 micron. Filtration efficiency of 99.9995% at 0.18 micron. Tested IEST-RP-CC001. U15 by MPPS method as per EN 1822. All of our ULPA vacuum systems are aerosol leak tested before leaving our facility - included
- Cleanroom compatible with ISO Class 4 (former Class 10). Can be used in the Pharmaceutical industry
- 3-stage filtration system, includes an ULPA (U15) filter, main cloth filter, and disposable filter bags
- Designed for use in contamination controlled environments
- Thru-Flow heavy duty motor
- Low noise level - only 60 dB(A) at 6.6' (2m)
- For dry recovery only
- Available with a plastic or stainless steel recovery tank
- Mounted on a 4-wheel dolly for easy maneuverability
- Includes a complete tool kit.

Specifications

CR-1 ULPA	110760A	110760AP	110762A	110762AP
Model Name	CR-1 ULPA	CR-1 ULPA	CR-1 ULPA	CR-1 ULPA
Type	Electric	Electric	Electric	Electric
Tension	120 V	120 V	120 V	120 V
Frequency	60 Hz	60 Hz	60 Hz	60 Hz
Phase	Single	Single	Single	Single
Wattage	1000 W	1000 W	1000 W	1000 W
Power	1.3 HP	1.3 HP	1.3 HP	1.3 HP
Amperage	8.3 A	8.3 A	8.3 A	8.3 A
Air Flow	96 CFM	96 CFM	96 CFM	96 CFM
Vacuum Pressure	99 " H ₂ O	99 " H ₂ O	99 " H ₂ O	99 " H ₂ O
Sound Level	60 dB(A)	60 dB(A)	60 dB(A)	60 dB(A)
Type of Power Outlet	120V	120V	120V	120V
Suction Inlet Port	1.5 "	1.5 "	1.5 "	1.5 "
Cart Type	4 Wheel Dolly (4W)	4 Wheel Dolly (4W)	4 Wheel Dolly (4W)	4 Wheel Dolly (4W)
Filter Cleaning	None	None	None	None
Dust Recovery Tank	4 Gal	4 Gal	4 Gal	4 Gal
Dry Recovery - Disposable Filter Bag	2 gal.	2 gal.	2 gal.	2 gal.
Length	16 "	16 "	16 "	16 "
Width	16 "	16 "	16 "	16 "
Height	22 "	22 "	22 "	22 "
Weight (Vacuum Only)	20 lb.	20 lb.	19 lb.	19 lb.
Cord Length	33 ft.	33 ft.	33 ft.	33 ft.

Please note that specifications are subject to change without notice

Use only recommended tools & accessories



ULPA Filter for CR-1 ULPA - Included



Main Cloth Filter - Included



A complete tool kit is included (Part No. 323495)



A package of 5 synthetic recovery bags is included (Part No. 212500)



CR-1 ULPA with Stainless Steel Recovery Tank



#214860 HEPA/ULPA Filter Protector/Housing Kit - Available